



# Toasters

## Prince Castle: Universal Rapid Toasters (340-URT)

### When

Daily

### Tools

*McD® All Purpose Super Concentrate (APSC)*

*KAYQUAT™ Sanitizer*

*OR*

*McD® Sanitizer*

*McD® Heavy-Duty Degreaser (HDD)*

*Clean Sanitizer-Soaked Towels*

*KAY® NO-SCRATCH™ Pad*

*URT Tool*

*Heat Resistant Gloves*

*Sanitizer Spray Bottle*

*Glass and Multi-Surface Cleaner Spray Bottle*

### Daily Procedure

1. Turn the unit to “CLEAN” mode by pushing the PRODUCT button and allow unit to reach appropriate temperature.
2. Once toaster has reached clean temperature, turn the unit “OFF” and disconnect power to the unit.
3. Put on heat resistant gloves.

**SAFETY: The toaster will be extremely hot and can cause severe burns if handled without using heat resistant gloves.**

4. Spray a clean, sanitizer-soaked towel with McD® HDD solution and wipe the top panel to remove soils. A KAY® NO-SCRATCH™ Pad can be utilized for heavy soils. Wipe with another sanitizer-soaked towel to remove cleaner and soil residue.
5. Spray a clean, sanitizer-soaked towel with McD® HDD solution, wipe the release gates and all areas of the Bun Buffering Landing Zone (BBLZ). A KAY® NO-SCRATCH™ Pad can be utilized for heavy soils on the release gates and BBLZ.

**SAFETY: Take caution in reaching the release gates. Do not attempt to clean the release gates through the top of the toaster as burns may result.**

For compression plates, place a non-scratch pad on the toaster cleaning tool, dip in Hi-Temp Grill Cleanser and lightly scrub the compression plates/ moving walls.

6. Wipe the release gates, compression plates and BBLZ with another clean, sanitizer-soaked towel to remove cleaner and soil residue.
7. Spray McD® Sanitizer solution on all areas of the BBLZ and allow to air dry.
8. Spray a clean, sanitizer-soaked towel with McD® HDD solution and wipe the exterior of the toaster.
9. Remove each sheet from the toaster.
10. Lay each release sheet on a clean, flat, dry surface. Spray McD® All-Purpose Super Concentrate (APSC) (HCS) on a clean, dry towel. Wipe the towel firmly across the sheet length-wise over its entire surface. Immediately, repeat this procedure with a clean, sanitizer-soaked towel to remove cleaner and soil residue. Spray sheet with KAYQUAT Sanitizer solution (HCS) and allow sheet to air dry.
11. Turn the release sheet and repeat the procedure.
12. Reassemble and connect power to the unit.