Calibration of dispense volumes on McDonalds Creamers SKMcD1p

Always perform calibration checks with new bag of cream and after pressing refill button for 3 seconds

For units before S/N SAHG (with J Hook)

- Install new bag of cream
- Press and hold refill button for 3 seconds (display should flash 00)
- Press 1 small, 2 medium and 1 large shot
- Total dispensed should be 3 oz, (3/8 oz for 1 shot)
- If not correct, then pull screw out past J hook as far as it will go
- Measure distance from J hook to head of screw
- Adjust so this distance = ³/₄"
- If still off, contact tech support @ 800-328-3329 (Call while in front of machine and provide serial number)
- (do not attempt to adjust controller in programming. Discrepency of dispense volume is caused by mechanical issue, not programming)

For units after S/N SAHJ (with cotter pin style – No J Hook)

- Install new bag of cream
- Press and hold refill button for 3 seconds (display should flash 00)
- Press 1 small, 2 medium and 1 large shot
- Total dispensed should be 3 oz, (3/8 oz for 1 shot)
- If not correct, then call technical support @ 800-328-3329 (Call while in front of machine and provide serial number)
- (do not attempt to adjust controller in programming. Discrepency of dispense volume is caused by mechanical issue, not programming)