

Warranty Cycle Count

- All warranty claims for 340-URT **MUST** include cycle count.

To retrieve cycle count

- When the toaster is in on press and hold the “I” button.
- While holding the “I” button scroll by pressing the “UP or DOWN” arrow until you find the Bun screen and the display shows the cycle count (see photo).



340-532