

# Cream Dispenser

Model SK-1



Daily Cleaning

Cream Dispenser

Model SK-1

## Product Identification



### Cleaning the dispenser

#### Tools and Supplies Required



Bucket, Clean and Sanitized Towels



Bucket, Soiled Towels



Gastro norm Metal Pan




Gloves, Neoprene



McD All Purpose Super Concentrate (APSC) solution


1

**Turn the Creamer off and remove empty creamer bag.** Pull and turn valve to release cream tube. Remove the cream bag from the compartment



2

**Clean drip tray.** Take the drip tray to 3 compartment sink to wash, rinse, and sanitize



3

**Wipe down creamer once it has defrosted completely.** Wipe down the cold block and inside of creamer with APSC and Sanitizer Solution.



4

**Refill Creamer.** Insert a new bag of cream into dispenser. Pull and turn valve to secure cream tube. Replace the drip tray.

